

料号：07. EA212. 00301-12
EA212（YOGA G3）说明书（英语+希腊语+罗马尼亚语），
材质：80g书纸 单色双面印刷，不过胶，风琴折，尺寸:54*80mm

 YOGA G3 (EA212) TWS Earbuds Before using this product, please read these instructions carefully and keep them.	WELCOME Thank you for choosing us. Our wireless earphones have a fashionable design, powerful functions, high compatibility and a true hands-free convenience when making calls and listening to music! WIRELESS TECHNOLOGY With the latest BT 5.3 wireless technology, you can enjoy hassle free music without any interruption and you don't have to face wire tangling issues. Wireless connection allows you to enjoy your music experience or calls without holding your mobile phone but the maximum distance between them shall be within 10 meters (about 30 feet). The wireless connection may be interfered by obstacles (such as walls) or other electronic devices. CONNECT YOUR DEVICE • Please keep your earbuds near your phone within 1m. • Open the charging box and the headset will automatically turn on; you can hear "Power on", in 2 seconds. It is search-pairing mode. • Turn on your mobile Bluetooth function, and search Bluetooth name "YOGA G3", click Bluetooth name "YOGA G3" to connect. • Upon successful pairing, you'll hear a "connected" sound from the earbuds and the light will turn off. OPERATING GUIDE In below instruction, Touch button refers to the multifunction button (please refer to FUNCTION KEY DESCRIPTION) Open the charging box, the headset will automatically turn on, put it in the charging box and close the charging box cover to shut down. • Play/Pause: Tap on once on the multifunction button (L/R) • Last song: Short press twice on left multifunction button • Next song: Short press twice on right multifunction button • AI voice assistant: Short press three times on the multifunction button • Answer phone call: Short press once on the multifunction button • End phone call: Short press once on the multifunction button FUNCTION KEY DESCRIPTION 1. Microphone 2. Multifunction Button 3. Indicator Light 4. Type-C Charging Port 5. Charging box indicator light Microphone Multifunction button Indicator Light Type-C Charging Port Charging box indicator light	CHARGING THE EARPHONES 1. Use the Type-C charging port to charge your Box. 2. It should take 2 hours to get fully charged. 3. It performs best after being fully charged. Please use DC-5V power to charge it. Cautions: Please note that the maximum voltage cannot exceed DC-5V. THE EARPHONES LED INDICATOR GUIDE Low power: a vocal message reminds "Battery low" and the red light is flashing. Charging: the red light is on. Fully charged: the light turns off. THE CHARGING BOX DISPLAY GUIDE Low powered light is flashing. Charging: the red light is on. If the green indicators are steady on, the battery is fully charged. RECONNECTION 1. The earphones will reconnect with your mobile phone automatically. 2. If it doesn't, please find previous paired Bluetooth name to click. It will be connected.	
 RIVERSONG TECHNOLOGY CO., LTD. Address: No. 1108 Tower B, Tian'an High-Tech Plaza Phase 1, Futian District, Shenzhen, Guangdong Official website: www.riversongtech.com	FAQ Why can't I find the earphones model on my phone? It might be because the earphones are power off, or the wireless connection function of your mobile phone encounters some issues. 1. Put the earbuds into the charging box again, then open the charging box and take out the earbuds, and search for pairing again. 2. Restart your phone and connect again. 3. Touch the multi-function button 6 times to restore to factory settings and search for connection again. Insert the earbuds into the charging case and close it. Then, open the charging case again to enter Bluetooth pairing mode. NOTE When the earphones are under pairing status, the wireless connection pairing with your mobile phone should be done within 5 minutes, otherwise your earphones will automatically power off. Why the earphones cannot be linked with my mobile phone using the wireless connection function? It might be because the wireless connection function on your device is not turned on; your earphones are connected to another device; or the earphones are still in pairing mode. 1. Please check if the wireless connection function on your device is turned on. 2. Please check and confirm your earphones are not connected to another device. 3. Please check if your earphones are in pairing mode Why can't I hear any sound from my earphones? It might be because the earphones' volume is down to minimum; the earphones are not well connected with your phone; or your earphones are not within the wireless connection working range. 1. Adjust volume on your phone. 2. Proceed to connection process again. 3. Keep your earphones within 10 meters from your mobile phone to respect the wireless connection working range. NOTE When your earphones and mobile phone are in pairing connection process, please do not do any other operations with those devices. When charging, why does the red light not lightening up? It might be because you did not use your earphones for a long time. Charge your earphones for 30 minutes until the red light is on. NOTE Overcharging or placing the earphones under high temperature atmosphere will cut down the battery capacity and lifetime.	Why the earphones call quality is not good? It might be because the mobile network is not good enough; or the earphones are not in the wireless connection working range. 1. Confirm whether the mobile network is strong enough. 2. Please confirm that the earphones are within the effective working distance of 10 meters from your mobile phone, also check if no major obstacle is causing interference to connection. When the music is playing, why the music cannot be controlled with the play/pause, previous/next song and volume up/down buttons? It might be because the mobile phone doesn't support the AVRCP (Audio/Video Remote Control Profile) protocol. This feature requires the mobile device to be paired with the earphones to support the AVRCP (Audio/Video Remote Control Profile) protocol.	SPECIFICATION Product name: YOGA G3 Model: EA212 Bluetooth version: V5.3 Connection distance: 10m Frequency response: 20Hz-20KHz Speaker size: Ø10mm Impedance range: 32Ω±5% Earbud battery: 40mAh Charging battery: 380mAh Input voltage: 5V=400mA Playback time: ~6H (volume at 70%) Charging port: Type-C
 RIVERSONG ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΗΣ	ΚΑΛΩΣ ΗΡΩΑΤΕ Σας ευχαριστούμε που μας επιλέξατε. Τα ασύρματα ακουστικά μας έχουν μοντέρνο σχεδιασμό, μεγάλη ισχύ, υψηλή συμβατότητα και πραγματική hands-free ευκολία για να απολαμβάνετε τις κλήσεις και τη μουσική σας! ΑΣΥΡΜΑΤΗ ΤΕΧΝΟΛΟΓΙΑ Με την πλέον σύγχρονη ασύρματη τεχνολογία BT 5.3 μπορείτε να απολαύσετε ελεύθερα τη μουσική σας αόκλινα και χωρίς να ασχολείστε με μετερδεμένα καλώδια. Η ασύρματη σύνδεση σας επιτρέπει να απολαμβάνετε τη μουσική σας και τις κλήσεις σας χωρίς να χρειάζεται να κρατάτε το κινητό σας τηλέφωνο, αλλά η μέγιστη απόσταση μεταξύ τους θα πρέπει να είναι 10 μέτρα. Η ασύρματη σύνδεση μπορεί να επηρεαστεί από εμπόδια (π.χ. τοίχους) ή άλλες ηλεκτρονικές συσκευές. ΣΥΝΔΕΞΤΕ ΤΗ ΣΥΣΚΕΥΗ ΣΑΣ • Κρατήστε τα ακουστικά σας κοντά στο τηλέφωνό σας σε απόσταση έως 1 μέτρο. • Ανοίξτε τη θήκη φόρτισης και τα ακουστικά θα ενεργοποιηθούν αυτόματα, θα ακούσετε ηχητική ειδοποίηση "Power on" σε 2 δευτ. και τα ακουστικά θα μπου σε λειτουργία σύζευξης. • Ενεργοποιήστε τη λειτουργία Bluetooth στο κινητό σας, αναζητήστε τη συσκευή "YOGA G3" στις συνδέσεις και κάντε κλικ σε αυτή για σύνδεση. • Μετά από την επιτυχή σύνδεση θα ακούσετε το ηχητικό μήνυμα "συνδέθηκε" από τα ακουστικά σας και η φωτεινή ένδειξη θα σβήσει. ΟΔΗΓΙΕΣ ΛΕΙΤΟΥΡΓΙΑΣ Στις παρακάτω οδηγίες, το Πλήκτρο Αφής (Touch button) αναφέρεται στο πλήκτρο πολλαπλών λειτουργιών (βλέπε στην Περιγραφή Στοιχείων Λειτουργιών). • Ανοίξτε τη θήκη φόρτισης, τα ακουστικά σας θα ενεργοποιηθούν αυτόματα, για να απενεργοποιηθούν τοποθετήστε τα στη θήκη φόρτισης και κλείστε το καπάκι. • Play/Pause (Αναπαραγωγή/Παύση): Αγγίξτε μία φορά το πλήκτρο πολλαπλών λειτουργιών (L/R). • Τελευταίο τραγούδι: Πατήστε σύντομα δύο φορές το αριστερό πλήκτρο πολλαπλών λειτουργιών. • Επόμενο τραγούδι: Πατήστε σύντομα δύο φορές το δεξιό πλήκτρο πολλαπλών λειτουργιών. ΦΩΝΗΤΙΚΕΣ ΒΟΗΘΟΣ ΑΙ: Πατήστε σύντομα τρεις φορές το πλήκτρο πολλαπλών λειτουργιών. • Απάντηση φωνητικής κλήσης: Πατήστε σύντομα μία φορά το πλήκτρο πολλαπλών λειτουργιών. • Τερματισμός φωνητικής κλήσης: Πατήστε σύντομα μία φορά το πλήκτρο πολλαπλών λειτουργιών. • Απορρίψη κλήσης: Πατήστε παρατεταμένα το πλήκτρο πολλαπλών λειτουργιών (L/R) για 2 δευτ. • Πατήστε παρατεταμένα το πλήκτρο πολλαπλών λειτουργιών (L/R) για 3 δευτ. για αναλογική επιλογή μεταξύ λειτουργίας παιχνιδιού και λειτουργίας μουσικής. ΠΕΡΙΓΡΑΦΗ ΣΤΟΙΧΕΙΩΝ ΛΕΙΤΟΥΡΓΙΑΣ 1. Μικρόφωνο 2. Πλήκτρο πολλαπλών λειτουργιών 3. Ενδεικτική λυχνία 4. Θύρα φόρτισης Type-C 5. Ενδεικτική λυχνία θήκης φόρτισης Μικρόφωνο Πλήκτρο πολλαπλών λειτουργιών Ενδεικτική λυχνία Θύρα φόρτισης Type-C Ενδεικτική λυχνία θήκης φόρτισης	ΦΟΡΤΙΣΗ ΤΩΝ ΑΚΟΥΣΤΙΚΩΝ 1. Φορτίστε τη θήκη μέσω της θύρας φόρτισης Type-C. 2. Για την πλήρη φόρτιση θα χρειαστούν 2 ώρες. 3. Η βέλτιστη λειτουργία επιτυγχάνεται μετά από πλήρη φόρτιση. Χρησιμοποιήστε τροφοδοσία DC-5V για τη φόρτιση. Προσοχή: Σημειώστε ότι η μέγιστη τάση δεν μπορεί να ξεπερνά τα DC-5V. ΟΔΗΓΟΣ ΕΝΔΕΙΚΤΙΚΗΣ ΛΥΧΝΙΑΣ LED ΑΚΟΥΣΤΙΚΩΝ Χαμηλή ισχύς: ακούγεται μία ηχητική υπενθύμιση "Battery low" και η κόκκινη λυχνία αναβοσβήνει. Φόρτιση: Η κόκκινη λυχνία είναι αναμμένη. Πλήρης φόρτιση: η λυχνία σβήνει. ΟΔΗΓΟΣ ΕΝΔΕΙΞΕΩΝ ΘΗΚΗΣ ΦΟΡΤΙΣΗΣ Χαμηλή ισχύς: η κόκκινη λυχνία αναβοσβήνει. Φόρτιση: Η κόκκινη λυχνία είναι αναμμένη. Ένα οι πράσινη ενδεικτική λυχνία είναι σταθερά αναμμένη, η μπαταρία είναι πλήρως φορτισμένη. ΕΠΙΛΕΞΤΕ ΤΗΝ ΕΠΙΛΟΓΗ 1. Τα ακουστικά θα επανασυνδεθούν με το κινητό σας τηλέφωνο αυτόματα. 2. Εάν δεν συμβεί αυτό, αναζητήστε το όνομα της συσκευής στις συνδέσεις Bluetooth και κάντε κλικ σε αυτό για να γίνει επανασύνδεση.	

正面

背面